
KARTNERS

224 COLLECTION


SINGLE SHOWER DOOR HANDLE

2247512/7518




- 1.Handle A
- 2.Clear Gasket x 4
- 3. Fixing Bracket x 2
- 4.End Cap x 2
- 5.Set Screw M5 x 2
- 6.Allen Key 2.5mm x 1


_	GLASS INFO			
		Α	Glass Hole C-C Distance	
			6"/152mm	6"Shower Door Handle
	1		8"/203mm	8"Shower Door Handle
Glass	→		12"/305mm	12"Shower Door Handle
1			18"/457mm	18"Shower Door Handle
			24"/610mm	24"Shower Door Handle
		В	1/2"(12mm)	Glass Hole Diameter
		С	6-12mm	Glass Thickness




Install the handle A (bolt) through the glass holes,make sure the rubber gaskets are between handle&glass.



Screw in the fixing brackets into the handle bolts.



Add the end caps on the fixing brackets, make sure the set screws holes in the bottom.



Fix the set screws on the end caps,tighten it to avoid loose from fixing brackets.